

Using your Vector Pro with Windows Vista/7 64-Bit Operating Systems

WARNING! For 64 bit Operating systems, in order to install and run the driver, the following procedure must be performed when starting up or rebooting the computer, in order for the drivers to work - this means when you first install the drivers, and, EVERY time you start up the computer when you wish to use your Vector Pro Launch System.

- a. Turn on the computer, as the computer starts up continuously tap the F8 function key on the keyboard.
- b. The Option screen will appear.
- c. Use the down arrow key to highlight "Disable Driver Signature Enforcement" and hit the Enter key, on the keyboard